

MANUAL
RETRACTABLE/ARTICULATED
SOFAS


Century

TECHNICAL INSTRUCTIONS AND PRECAUTIONS


- It is recommended to line the floor to avoid damaging the product when attaching the legs or base.
- Check that the number of legs received is in accordance with the number of arrows identified on the lining.
- Avoid bumping and resting the product on objects with sharp edges.
- Avoid sitting on the armrests and backrests and jumping on the product.




- Do not use the product as a stand or ladder.
- Do not jump on the sofa.
- Do not drag or lift only one side of the product to move the product.



- When moving the sofa, move together with another person, lifting both ends of the module.



- Some fabrics generate excess material more easily, as this is a characteristic of this material and is not considered a defect. Smooth the surface of the fabric so that excess material is less apparent.




- In case of doubts, please contact us through our service channels available on the website: www.meucentury.com.

CONNECTORS/COUPLINGS


Your articulated sofa may have four types of connectors, identify which connector is included in your module and follow the instructions. Connectors/couplings are already installed.

- Snap Connector
- Male / Female
- Cross Arm Brace Connector
- Threaded Rod Connector


1- Snap Connector



Align the modules to be connected.




Push one module towards the other so that the connector engages.



2- Male/Female




Align the modules to be connected.




Lift the aligned modules so that one connector engages the other and carefully lower the already engaged modules.




3- Cross Arm Brace Connector



Align the modules that will be connected.




Lift one of the aligned modules so that one connector fits into the other and carefully lower the already engaged module.



4- Threaded Rod



Position the sofas with the bottom facing sideways, align the two modules and open the NW (Non-Woven Fabric) zipper located at the bottom of the two modules, position one side of the connector on one of the modules and thread through the hole, located on the inside of the sofa.



Thread the handle onto the screw to connect the two modules and close the zipper.

OPERATION OF MOTORIZED AND MANUAL RETRACTABLE SOFAS

Congratulations on selecting a sofa with retractable seats! Sofas with this added feature offer comfort and versatility to any room. This manual will provide detailed instructions on how to use sofas with electric and manual retractable seats correctly and safely, ensuring a satisfying experience.

Motorized Retractable Sofa

Step 1: Identifying Controls

Locate the buttons to adjust the seats, which are located on the seat, next to the armrest. Become familiar with the buttons and their functions.



Step 2: Positioning the Seats

Check that the sofa seats are in the correct position before using the buttons. Make sure that the seats are pushed back completely, ensuring that the electric mechanism works correctly during adjustments.

Step 3: Setup the function

Connect the modules with the connectors and plug the power supply into the socket. After that, setup the function.


There are two types of functions:

- Manual: Touch and hold the button until fully open.
- Automatic: Touch the button once and the sofa will open fully automatically. To stop, simply touch any of the buttons.

In order to change the function, it is necessary to plug the power cord into the socket and immediately after, hold the two buttons at the same time for 10 seconds. If you want to change the function again, repeat the same procedure.

Step 4: Using the mechanism

Use the electric buttons to adjust the sofa seats according to your preference. The front button will always be used to open the sofa, while the back button will be used to close it. The operation of the buttons follows the configuration of the selected function.



Manual Retractable Sofas

Step 1: Identification of mechanisms

There are three types of mechanisms:


1. Lever mechanism: pull the lever and move the seat to any position.
2. Lift mechanism: lift and move the seat to any position.
3. Two positions: either fully pull or fully push the seat, restricted to two positions.

Step 2: Seat Positioning

As with motorized retractable sofas, check that the sofa seats are in the correct position before using the manual mechanisms. Make sure that the seats are pushed back completely, ensuring that the manual mechanisms work properly during adjustments.

Step 3: Using the mechanism

Use manual mechanisms to adjust the sofa seats.




Operation of backrests with ratchet


Position adjustment

To adjust the backrest, please follow the steps below:

Step 1: Raise the backrest to the desired position. The ratchet should lock automatically and hold the backrest in the desired position.



Step 2: To unlock, push the backrest all the way down, as indicated by the arrow, and return to the horizontal position.





meucentury.com | [@meucentury](https://www.instagram.com/meucentury)